

Pocket*Memo*

WLAN adapter

Direct file upload

Security features

Web browser interface



ACC8160



Streamline your workflow

with direct file upload via WiFi

The innovative Philips WLAN adapter instantly sends your files from the dictation recorder to your transcriptionist. Just dock the recorder to upload your dictation files directly to the company network using built-in WiFi. Administrators can easily deploy automatic firmware updates for PocketMemo dictation recorders via an easy Web browser interface.

Easy and intuitive

- · Direct file upload from the recorder to the network for faster turnaround time
- · Seamless and simple use with no user configuration or training required
- · Easy implementation without investment in additional hardware

Maximum security

- · Wireless security features and FTPS support for secure file transfer
- · Password protection for safeguarding configuration access
- · Kensington security slot for theft protection

Designed for detail

- · Automatic firmware updates for dictation recorders for efficient device management
- · Web browser interface for easy and quick setup and configuration
- Optional administration software for remote management of multiple WLAN adapters



Highlights

Direct file upload



Just dock your dictation recorder into the WLAN adapter and enjoy the easiest way to transfer your dictation files in seconds to the transcriptionist.

Seamless and simple use



The WLAN adapter is simple to use and requires no end-user training or configuration. Users just dock their recorder to upload dictation files.

Easy implementation



The average annual maintenance costs for a PC are four to seven times the acquisition costs. In contrast, WLAN adapters are easy to deploy and manage, reducing your IT maintenance costs.

Security features



End-to-end encryption with DSS file encryption and secure FTP transfer as well as wireless industry-standard security features ensure that sensitive information remains confidential. Having no local storage capability, the WLAN adapter is not vulnerable to viruses or other malicious software. File upload is limited to dictation sound files (.dss/.ds2, .wav, .mp3), thus prohibiting that the WLAN adapter is used to upload harmful files to the network.

Password protection



The configuration interface is password protected for safeguarding device configuration from unauthorized access.

Theft protection



Use the Kensington lockdown equipment to secure the adapter to a desktop or other surface, protecting it against theft.

Efficient device management



Deploy automatic firmware updates for Philips PocketMemo dictation recorders. The firmware will be updated automatically the next time the recorder is connected to the WLAN adapter.

Web browser interface



The streamlined configuration interface can be accessed via Web browser, making it is easy to use without any software installation.

Optional administration software



Use the optional administration software to manage and update multiple WLAN adapters remotely. Get a quick overview of the status of the WLAN adapters connected to your network and update configuration and settings from a centralized user interface.













Specifications

Connectivity

USB: for PocketMemo digital dictation recorder Micro USB: for DC 5V power supply LAN Ethernet: 10/100 Mbit/s

WLAN antenna connector

Compatibility

Philips PocketMemo dictation recorder: DPM8000 series, LFH9600 series Philips PocketMemo docking station: ACC8120, LFH9120

WiFi standards

IEEE 802.11b IEEE 802.11g IEEE 802.11n

Security

Wi-Fi Protected Access (WPA/WPA2) Kensington security slot

LEDs

LAN status Recorder status

Power

Power supply: 5 V DC / 1800 mA Power consumption: 500 mA (without connected recorders)

System requirements WLAN adapter

FTP or FTPS server with a user account for the WLAN adapter DHCP server (recommended)

System requirements administration

Processor: Pentium 4, 1 GHz or equivalent processor

RAM memory: 1 GB

Hard disk space: 10 MB for the administration software, 850 MB (32 bit) / 2 GB (64 bit) for

Microsoft .NET Framework

Operating system: Windows 8/7/Vista (32/64 bit), Windows Server 2008/2008 R2/2003 SP 2

Microsoft .NET Framework 4.0 Microsoft Windows Installer 3.1 LAN connection

Operation conditions

Temperature: $5^{\circ} - 45^{\circ} \text{ C} / 41^{\circ} - 113^{\circ} \text{ F}$ Humidity: 10 % - 90 %, noncondensing

Green specifications

Compliant to 2011/65/EU (RoHS) Lead-free soldered product

Dimensions

Product dimensions (W×D×H): $100\times100\times25\,\text{mm}\,/3.94\times3.94\times0.98\,\text{inches}$ Net weight: 270 g / 10 oz

Package contents

WLAN adapter Power supply Ethernet cable USB cable Micro USB cable WLAN antenna Quick start guide



© 2016 Speech Processing Solutions GmbH. All rights reserved.

Specifications are subject to change without notice. Philips and the Philips shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.



Issue date 2016-12-13

Version 1.0