

Philips
Desktop transcription
system

Mini cassette

LFH0730T



Simply working smarter

with Philips transcription solutions

The Philips desktop transcription system is a document creation solution specifically designed to make transcription easy and intuitive. With the ergonomic foot pedal for hands-free playback control and the professional transcription headphones, the desktop transcription system takes transcription to a new level. The secret of the transcription system 730 is its easy and fast access to any part of the tape.

Enhance your productivity

- Auto rewind for fast return to the beginning of the tape
- Search forward and skip functions for quick access to the start of the next recording
- Audible scan for monitoring fast forward and rewind
- Can be used as both a dictation and transcription machine with additional accessories

Superior audio quality

- Ergonomic foot pedal for convenient playback control
- Lightweight stereo headphones for enhanced wearing comfort
- Tone, speed and volume controls for crystal clear playback at all times
- Integrated speaker ensuring crystal clear playback

Designed for professionals

- Workflow display for showing important information at a glance
- Auto backspace pauses transcription without missing a word
- Record protection for saving valuable dictations
- Turbo wind for fast access to any part of the tape

PHILIPS
sense and simplicity

Specifications

Desktop transcription machine

- Headphones: 3.5 mm
- Foot pedal: 3.5 mm
- Microphone: RJ-14
- Power supply: 12 V DC
- Frequency: 200–6,000 Hz
- Output power: >600 mW
- Product dimensions: 135 mm × 232 mm × 50 mm/5.3" × 9.1" × 2.0"
- Weight: 1150 g/39 oz

Headphones

- Acoustic system: open
- Magnet type: neodymium
- Sound quality: optimized for voice reproduction
- Impedance: 64 Ohm
- Maximum power input: 2 × 10 mW
- Sensitivity: 103 dB
- Speaker diameter: 14 mm
- System: dual sound system
- Cable connection: one-sided
- Cable length: 3 m/10 ft
- Connector: 3.5 mm stereo, right angled
- Connector finish: gold-plated
- Product dimensions (W × D × H): 226 mm × 130 mm × 25 mm/9" × 5" × 1"
- Weight: 100 g/3.5 oz

Green specifications

- Compliant to 2002/95/EC (RoHS)
- Lead-free soldered product

Package contents

- Dictation and transcription machine LFH0730
- Foot pedal LFH2210
- Transcription headphones LFH0234
- Power supply LFH0155

Accessories

- Philips headphones LFH0232, LFH0233, LFH0334, LFH2236
- Philips handheld microphone LFH0276/00
- Philips meeting microphone LFH9172

Highlights

Auto rewind

Auto rewind allows you to save time by quickly returning to the beginning of the tape automatically.

Search functions

Search forward and skip functions allow quick access to the start of the next recording, making it easier to navigate through your recordings.

Audible scan

Audible scan allows you to find specific parts of dictations easily.

Versatile functionality

The Philips multifunctional handheld remote microphone LFH0276/00 with built-in speaker turns your Philips desktop transcription system into a dictation recorder.

Ergonomic foot pedal

Slim, ergonomic design guarantees hands-free control of all playback functions with minimal physical strain.

Lightweight stereo headphones

Lightweight under-the-chin style stereo headphones designed to deliver excellent sound quality, with soft ear cushions for enhanced wearing comfort.

Volume, tone and speed controls

Variable tone, speed and volume controls guarantee crystal clear playback and provide all the necessary features for transcription accuracy.

Crystal clear playback

The built-in front speaker guarantees crystal clear playback of your dictation files.

Workflow display

The large display shows all the information needed to manage the workload. It shows important information such as cassette length and remaining recording time.

Auto backspace

The auto backspace automatically replays the last few seconds to review recorded material for transcribing confirmation and accurate and fast transcription.

Record protection

You can safeguard valuable dictations using the record protection function. This way you will never accidentally record over valuable recordings.

Turbo wind

The turbo wind function allows you to jump to any part of the tape within seconds and save you valuable time.



Issue date 2014-07-21

Version 1.0

© 2014 Koninklijke Philips Electronics N.V.
All rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com/dictation